

# Aircraft Specialty Products

## WATER BREAK FREE KIT



### *Product description:* WATER BREAK FREE KIT

#### FEATURES:

- ▶ Kit consists of a Scotch-Brite™ Pad saturated with an alkaline Calla® 805 cleaner, a towelette saturated with DI water, and a dry towelette.

#### AVAILABLE PACK SIZES:

- ▶ Available as a kit-008538]

#### KEY BENEFITS:

- ▶ Prepares metal surfaces for further treatment
- ▶ Makes surface clean so that it forms a water break free surface

#### SPECS:

- NSN: 6850-01-524-8291 (Kit)

#### APPLICATIONS

- ✓ Remove the Scotch-Brite™ Pad, saturated with Calla® 805 alkaline cleaner, from its package.
- ✓ Abrade the metal surface with the Scotch-Brite™ Pad by abrading the surface in two directions at 90 degrees from each other.
- ✓ Remove the towelette saturated with DI water and wipe the abraded area to remove excess soap.
- ✓ Remove the dry towelette and wipe the abraded surface dry.
- ✓ Test the abraded spot with water to see if it is water break free. If not, repeat steps 1-5. If the area is water break free, then continue with the surface treatment.

Scotch-Brite™ is a trademark of 3M.

Rev: 20081A  
08-03-2021

 For more information contact us :  
[zipchem@addevmaterials.com](mailto:zipchem@addevmaterials.com)

