



Sur-Prep®

SURFACE PREPARATION & AVIONICS CLEANERS

SUR-PREP® 3500-1 KIT

Product description:
**NON-DECORATIVE INTERIOR
STRUCTURE SURFACE PREP KIT**

FEATURES:

- ▶ Alkaline cleaning solution pad (Step 1)
 - ▶ Deionized water wipe and dry towel (Step 2)
 - ▶ Citra-Safe® deodorized wipe and dry towel (Step 3)
 - ▶ Conversion coating material wipe (Step 4)
 - ▶ Deionized water wipe and dry towel (Step 5)
-

AVAILABLE PACK SIZES:

- ▶ 12 gram kit-104089]
 - ▶ 1 oz kit-104090]
-

(Caution: Citra-Safe® Deodorized Wipe and Dry Towel is Combustible! Avoid skin and eye contact. In case of skin contact, remove contaminated clothing and wash skin thoroughly with soap and water. If splashed into eyes, flush eyes with water for at least 15 minutes or until the irritation subsides. Wear nitrate gloves and safety glasses or goggles when handling this product. Consult SDS for additional information.)



Rev: 29164B
09-02-2021

 For more information contact us :
zipchem@addevmaterials.com

 Part of 



Sur-Prep®

SURFACE PREPARATION & AVIONICS CLEANERS

SUR-PREP® 3500-1

KIT

Product description:

NON-DECORATIVE INTERIOR STRUCTURE SURFACE PREP KIT

(**Danger:** Conversion Coating Material Wipe contains a chromic acid mixture. Corrosive to skin and eyes. Avoid skin and eye contact. Avoid breathing mist from solution. Wear safety goggles or face shield and nitrile gloves when handling this product. In case of eye contact, flush eyes with water for at least 15 minutes, and then seek medical attention. Consult SDS for additional information.)

APPLICATIONS:

- ✓ Clean and conversion coat mating surfaces prior to painting or sealing
- ✓ Steps:
 - A) Remove any loose paint or sealant with a micarta scraper
 - B) Remove any loose debris, metal shavings, and dirt via vacuum
 - C) Lightly abrade entire area of parts to be sealed or painted using Scotch-Brite™ with alkaline cleaner (Step 1). Be sure to remove the alcad identification marking.
 - D) Wipe area with deionized water towel (Step 2) to remove soap residue immediately followed with the dry wipe
 - E) Repeat with a second water wipe and dry the area
 - F) Solvent clean area with Deodorized Citra-Safe® wipe (Step 3). Do not allow the solvent to dry on the surface. Wipe it with the dry wipe.
 - G) Apply conversion coating material by placing the unfolded conversion coating material towel (Step 4) on the surface. Allow the towel to sit on the surface for 2-5 minutes. Do not allow the conversion coating material to dry on the surface.
 - H) Neutralize the conversion coating material by wiping with Deionized water (Step 5). Immediately follow with the dry wipe

 For more information contact us :
zipchem@addevmaterials.com

 Part of 



Sur-Prep®

SURFACE PREPARATION & AVIONICS CLEANERS

SUR-PREP® 3500-1

KIT

Product description:

NON-DECORATIVE INTERIOR STRUCTURE SURFACE PREP KIT

APPLICATIONS:

I) Place all used towels in plastic bag. Remove all air from the bag and seal. Dispose of plastic bag as hazardous waste. (**Caution:** DO Not allow Conversion Coating Material Towels to dry or spontaneous combustion may occur). Be sure to remove air, seal the bag, and dispose of properly.)

J) Apply paint or sealant within two hours, if required

Citra-Safe® is manufactured by Inland Technology Inc.

Citra-Safe® is a registered trademark of Inland Technology Inc.

Scotch-Brite™ is a trademark of 3M.



For more information contact us :
zipchem@addevmaterials.com



Part of



ADDEVMATERIALS