

# Aircraft Specialty Products

## WATER BREAK FREE KIT



### *Product description:* WATER BREAK FREE KIT

---

#### FEATURES:

- ▶ Kit consists of a Scotch-Brite™ Pad saturated with an alkaline **Calla® 805** cleaner, a towelette saturated with DI water, and a dry towelette.
- 

#### KEY BENEFITS:

- ▶ Prepares metal surfaces for further treatment
  - ▶ Makes surface clean so that it forms a water break free surface
- 

#### SPECS:

- NSN: 6850-01-524-8291 (Kit)
- 

#### APPLICATIONS

- ✓ If water is applied to the surface, then the surface should be cleaned with a **Water Break Free Kit**
- ✓ Remove the Scotch-Brite™ Pad, saturated with **Calla® 805** alkaline cleaner, from its package
- ✓ Abrade the metal surface with the Scotch-Brite™ Pad by abrading the surface in two directions at 90 degrees from each other
- ✓ Remove the towelette saturated with DI water and wipe the abraded area to remove excess soap
- ✓ Remove the dry towelette and wipe the abraded surface dry
- ✓ Test the abraded spot with water to see if it is water break free. If not, repeat steps 1-5. If the area is water break free, then continue with the surface treatment.

Rev: 20082A  
10-29-2021

# Aircraft Specialty Products

## WATER BREAK FREE KIT



*Product description:*  
**WATER BREAK FREE KIT**

---

### **AVAILABLE PACK SIZES:**

- ▶ Available as a kit-008538
- 

Scotch-Brite™ is a trademark of 3M.



For more information contact us :  
[zipchem@addevmaterials.com](mailto:zipchem@addevmaterials.com)



Part of



**ADDEVMATERIALS**