

Aircraft Specialty Products

WATER BREAK FREE KIT



Page 1 of 2

Product description: WATER BREAK FREE KIT

FEATURES:

- ▶ Kit consists of a Scotch-Brite™ Pad saturated with an alkaline **Calla® 805** cleaner, a towelette saturated with DI water, and a dry towelette.
-

KEY BENEFITS:

- ▶ Prepares metal surfaces for further treatment
 - ▶ Makes surface clean so that it forms a water break free surface
-

SPECS:

- NSN: 6850-01-524-8291 (Kit)
-

APPLICATIONS

- ✓ If water is applied to the surface, then the surface should be cleaned with a **Water Break Free Kit**
- ✓ Remove the Scotch-Brite™ Pad, saturated with **Calla® 805** alkaline cleaner, from its package
- ✓ Abrade the metal surface with the Scotch-Brite™ Pad by abrading the surface in two directions at 90 degrees from each other
- ✓ Remove the towelette saturated with DI water and wipe the abraded area to remove excess soap
- ✓ Remove the dry towelette and wipe the abraded surface dry
- ✓ Test the abraded spot with water to see if it is water break free. If not, repeat steps 1-5. If the area is water break free, then continue with the surface treatment.

Rev: 20082B
10-13-2023

Aircraft Specialty Products

WATER BREAK FREE KIT



Page 2 of 2

Product description:
WATER BREAK FREE KIT

AVAILABLE PACK SIZES:

Water Break Free Kit

- ▶ Available as a kit-008538

Calla® 805

- ▶ Case of 4 each Gallon (4 each of 3.8 Liter) Bottles-002027
 - ▶ 5 Gallon (18.9 Liter) Pails-002028
 - ▶ 55 Gallon (208 Liter) Drums-002029
 - ▶ 330 Gallon (1249 Liter) Totes-009766
 - ▶ Special Packaging Upon Request
-

Scotch-Brite™ is a trademark of 3M.

 For more information contact us :
zipchem@addevmaterials.com

