

Aircraft Specialty Products

WATER BREAK FREE KIT



Page 1 of 2

Product description:

WATER BREAK FREE KIT

FEATURES:

- ▶ Kit consists of a Scotch-Brite™ Pad saturated with an alkaline **Calla® 805** cleaner, a towelette saturated with DI water, and a dry towelette.

KEY BENEFITS:

- ▶ Prepares metal surfaces for further treatment
- ▶ Makes surface clean so that it forms a water break free surface

SPECS:

- NSN: 6850-01-524-8291 (Kit)

APPLICATIONS

- ✓ If water is applied to the surface, then the surface should be cleaned with a **Water Break Free Kit**
- ✓ Remove the Scotch-Brite™ Pad, saturated with **Calla® 805** alkaline cleaner, from its package
- ✓ Abrade the metal surface with the Scotch-Brite™ Pad by abrading the surface in two directions at 90 degrees from each other
- ✓ Remove the towelette saturated with DI water and wipe the abraded area to remove excess soap
- ✓ Remove the dry towelette and wipe the abraded surface dry
- ✓ Test the abraded spot with water to see if it is water break free. If not, repeat steps 1-5. If the area is water break free, then continue with the surface treatment.
- ✓ Store the **Water Break Free Kit** in a cool, dry, well-ventilated place at a temperature below 120°F (49°C).

Rev: 20083C
05-01-2025



For more information contact us :
zipchem@addevmaterials.com



Part of



ADDEV
MATERIALS

Aircraft Specialty Products

WATER BREAK FREE KIT



Page 2 of 2

Product description: **WATER BREAK FREE KIT**

AVAILABLE PACK SIZES:

Water Break Free Kit

- ▶ Available as a kit-008538

Calla® 805

- ▶ Case of 4 each Gallon (4 each of 3.8 Liter) Bottles-002027
 - ▶ 5 Gallon (18.9 Liter) Pails-002028
 - ▶ 55 Gallon (208 Liter) Drums-002029
 - ▶ 330 Gallon (1249 Liter) Totes-009766
 - ▶ Special Packaging Upon Request
-

Scotch-Brite™ is a trademark of 3M.



For more information contact us :
zipchem@addevmaterials.com



Part of



ADDEV
MATERIALS