

Aircraft Specialty Products

Water Break Free Kit Instruction Manual

Page 1 of 2

Safety Steps and Procedures To Follow Prior To Applying The Water Break Free Kit:

Always refer to the safety data sheet (SDS), technical data sheet (TDS), and label prior to applying **Water Break Free Kit** if you have any questions about this product.

Always wear gloves, protective eyewear, and protective clothing when handling **Water Break Free Kit** to prevent the material from making contact with the skin and eyes.

Water Break Free Kit Features and Benefits:

The **Water Break Free Kit** consists of a Scotch-Brite™ Pad saturated with an alkaline **Calla® 805** cleaner, a towelette saturated with DI water, and a dry towelette.

The **Water Break Free Kit** prepares a metal surface for further treatment by making the surface clean so that it forms a **water break free surface**.

Places Where Water Break Free Kit Should Be Applied:

The **Water Break Free Kit** should be applied on metal surfaces that need to be prepared for further treatment after water is applied to it.

Procedures For Applying The Water Break Free Kit:

- 1.) Remove the **Scotch-Brite™ Pad**, saturated with the **Calla® 805 alkaline cleaner** from its package.
- 2.) Abrade the metal surface with the **Scotch-Brite™ Pad** by abrading the surface in **two directions** at **90 degrees** from each other.
- 3.) Remove the **towelette** saturated with **DI water** and wipe the abraded area to remove excess soap.
- 4.) Remove the **dry towelette** and wipe the abraded surface dry.
- 5.) Test the abraded spot with water to see if it is **water break free**. If not, repeat **steps 1-5**. If the area is **water break free**, continue with the surface treatment.

Aircraft Specialty Products

Water Break Free Kit Instruction Manual

Page 2 of 2

Water Break Free Kit Product Packaging Part Numbers and Additional Materials To Order:

Water Break Free Kit

*Kit consists of a Scotch™ Brite Pad saturated with Calla® 805 alkaline cleaner, a towelette saturated with DI water, and a dry towelette

*Available as a kit-**008538**

Calla® 805

*Case of 4 each Gallon (4 each of 3.8 Liter) Bottles-**002027**

*5 Gallon (18.9 Liter) Pails-**002028**

*55 Gallon (208 Liter) Drum-**002029**

*330 Gallon (1249 Liter) Tote-**009766**

*Special packaging upon request

Protective Eyewear

Protective Clothing

Gloves

Water Break Free Kit NSN: 6850-01-524-8291 (Kit)

For application questions regarding the **Water Break Free Kit**, contact **Zip-Chem® Aviation Products** at **(1) 408 782 2335** or **zipchem@addevmaterials.com**.



For more information contact us :
zipchem@addevmaterials.com



Part of



ADDEV
MATERIALS