

SUR-PREP® 3500-1

KIT

Page 1 of 3

Product description:

NON-DECORATIVE INTERIOR STRUCTURE SURFACE PREP KIT

FEATURES:

- ▶ Alkaline cleaning solution pad (Step 1)
- ▶ Deionized water wipe and dry towel (Step 2)
- ▶ Sur-Prep® 3167 (Step 3)
- ▶ Conversion coating material wipe (Step 4)
- ▶ Deionized water wipe and dry towel (Step 5)



(Caution: Sur-Prep® 3167 is Combustible! Avoid skin and eye contact. In case of skin contact, remove contaminated clothing and wash skin thoroughly with soap and water. If splashed into eyes, flush eyes with water for at least 15 minutes or until the irritation subsides. Wear nitrile gloves and safety glasses or goggles when handling this product. Consult SDS for additional information.)

(Danger: Conversion Coating Material Wipe contains a chromic acid mixture. Corrosive to skin and eyes. Avoid skin and eye contact. Avoid breathing mist from solution. Wear safety goggles or face shield and nitrile gloves when handling this product. In case of eye contact, flush eyes with water for at least 15 minutes, and then seek medical attention. Consult SDS for additional information.)

Rev: 29167E
08-10-2026

SUR-PREP® 3500-1

KIT

Page 2 of 3

Product description:

NON-DECORATIVE INTERIOR STRUCTURE SURFACE PREP KIT

APPLICATIONS:

- ✓ Prepares interior structure, fuel tank structure, and wing structure surfaces for **painting** and **sealing**
 - ✓ **Clean** and **conversion coat mating surfaces** prior to **painting** or **sealing**
 - ✓ Steps :
 - A) **Remove** any loose paint or sealant with a **micarta scraper**
 - B) **Remove** any loose debris, metal shavings, and dirt via **vacuum**
 - C) **Lightly abrade** entire area of parts to be **sealed** or **painted** using Scotch-Brite™ with alkaline cleaner **(Step 1)**. Be sure to **remove** the **alcad identification marking**.
 - D) **Wipe** area with deionized water towel **(Step 2)** to **remove soap residue** immediately followed with the dry wipe
 - E) **Repeat** with a **second water wipe** and **dry** the area
 - F) **Clean** area with **Sur-Prep® 3167 (Step 3)**. Do not allow **Sur-Prep® 3167** to **dry** on the surface. **Wipe** it with the **dry wipe**.
 - G) Apply conversion coating material by placing the unfolded conversion coating material towel **(Step 4)** on the surface. Allow the **towel** to **sit** on the surface for **2-5 minutes**. Do not allow the conversion coating material to **dry** on the surface.
 - H) **Neutralize** the conversion coating material by **wiping** with Deionized water **(Step 5)**. Immediately follow with the dry wipe
 - I) Place all **used towels** in **plastic bag**. **Remove** all air from the **bag** and **seal**. Dispose of **plastic bag** as **hazardous waste**.
- (Caution: Do Not allow Conversion Coating Material Towels to dry or spontaneous combustion may occur). Be sure to remove air, seal the bag, and dispose of properly.)

SUR-PREP® 3500-1

KIT

Page 3 of 3

Product description:

NON-DECORATIVE INTERIOR STRUCTURE SURFACE PREP KIT

APPLICATIONS (CONTINUED FROM PAGE 2):

- ✓ J) Apply **paint** or **sealant** within **two hours**, if required
- ✓ Refer to the **Sur-Prep® 3500-1 application manual** for detailed application instructions. This **manual** can be obtained by reaching out to your **Zip-Chem®** for a copy of this document.

AVAILABLE PACK SIZES:

Sur-Prep® 3500-1

- ▶ 12 gram (0.42 oz) kit-104087
- ▶ 1 oz (28 gram) kit-104088

Sur-Prep® 3167

- ▶ Case of 12 of 16 fl oz (473 mL) Aerosols-103765
- ▶ Case of 4 each Gallon (4 each of 3.8 Liter) Cans-103762
- ▶ 5 Gallon (18.9 Liter) Pail-103763
- ▶ 55 Gallon (208 Liter) Drum-103764
- ▶ Special Packaging Upon Request

Scotch-Brite™ is a trademark of 3M.