

# **Zip-Chem<sup>®</sup> Aerosol Trigger Sprayer**



## **Description:**

The Zip-Chem<sup>®</sup> Aerosol Trigger Sprayer is an ergonomic handle for using any Zip-Chem<sup>®</sup> aerosol can. The Zip-Chem<sup>®</sup> Aerosol Trigger Sprayer is a convenient trigger sprayer attachment for any Zip-Chem<sup>®</sup> aerosol can.

## **Instructions:**

The Zip-Chem<sup>®</sup> Aerosol Trigger Sprayer has a convenient collar mechanism opposite the handle which wraps securely around the neck of the Zip-Chem<sup>®</sup> aerosol can.

- 1) To attach the trigger sprayer to the aerosol can, move the lever to open the collar of the trigger sprayer.
- 2) Place the collar over the neck of the aerosol can until it rests firmly on the can and move the lever to close the collar around the neck of the aerosol can.
- 3) Lift the shield in the collar.
- 4) While attached to the aerosol can, turn the aerosol can in the trigger sprayer until the opening of the aerosol actuator is positioned at the opening in the collar.
- 5) Point the Zip-Chem<sup>®</sup> Aerosol Trigger Sprayer in the direction you want to spray, much like a paint spray gun.
- 6) Pull the trigger and apply the product as directed by its corresponding Technical Data Sheet.
- 7) To remove the Zip-Chem<sup>®</sup> Aerosol Trigger Sprayer, move the lever into the open position and pull the trigger sprayer off the top of the aerosol can.



## **Packaging:**

The Zip-Chem<sup>®</sup> Aerosol Trigger Sprayer is available as part number (010040)



## **ZIP-CHEM<sup>®</sup> AVIATION PRODUCTS**

**400 JARVIS DRIVE, MORGAN HILL, CA 95037**  
**PHONE: 1-800-648-2661 408-782-2335 FAX: 408-782-6304**  
**WWW.ZIPCHEM.COM**

Rev: 9654 C  
6/12/2019