



AIRCRAFT CLEANERS & DISINFECTANTS

CALLA® 1452



Page 1 of 11

Product description: **NEUTRAL DISINFECTANT CLEANER**

FEATURES:

- ▶ **Calla® 1452** eliminates **99.9%[^]** of the virus that causes **COVID-19***** on *hard non-porous surfaces in 1 minute!*
[^]when used according to disinfection directions
****SARS-Related Coronavirus 2*
- ▶ A phosphate-free disinfectant and cleaner
- ▶ A Disinfectant
- ▶ A Detergent and Deodorizer
- ▶ A Virucide
- ▶ A Fungicide (**Pathogenic Fungi**)
- ▶ A Mildewstat (**On Hard Non-Porous, Inanimate Surfaces**)



Calla® 1452 has demonstrated effectiveness against viruses similar to the **Marburg** and **Monkeypox** viruses on hard non-porous surfaces. Therefore, **Calla® 1452** can be used against the **Marburg** and **Monkeypox** viruses when used in accordance with the directions for use against **Rotavirus (ATCC VR 899)** on hard non-porous surfaces. Refer to the CDC website at <https://www.cdc.gov/vhf/marburg/index.html> and <https://www.cdc.gov/poxvirus/monkeypox/index.html> for additional information. Please see the most current EPA approved master label for product eligibility and for further details.

KEY BENEFITS:

- ▶ Provides effective cleaning, deodorizing, and disinfecting

Rev: 20071M
12-02-2024

 For more information contact us :
zipchem@addevmaterials.com



Part of



ADDEV
MATERIALS



AIRCRAFT CLEANERS & DISINFECTANTS

CALLA® 1452



Page 2 of 11

Product description:

NEUTRAL DISINFECTANT CLEANER

KEY BENEFITS (CONTINUED FROM PAGE 1):

- ▶ Disinfects hard, non-porous, and inanimate environmental surfaces, such as glazed ceramic tile, plastic surfaces, floors, walls, metal surfaces, windows, toilets and sinks, mirrors, sealed granite, doorknobs, sealed fiberglass, chairs, desks, stainless steel surfaces, and glazed porcelain (**when used as directed**)

SPECS:

- Airbus Canada CML 11-117
- Airbus CML 11AAA2
- AMS 1452 (Disinfectant Aircraft, General Purpose) (Meets requirements)
- AMS 1530B (Wipe-Off Cleaner) (Meets requirements)
- AMS 1550B (Cleaner for Interior) (Meets requirements)
- NAVAIR: 01-1A-509-2
- AMS 1453 (Disinfectant Cleaner For Aircraft Interior) (Meets requirements)
- Boeing BSS7434 (S/S D6-7127) (Meets requirements)
- Boeing D6-17487 (Meets requirements)
- NSN: 6840-01-600-4177 (5 Gallon (18.9 Liter) Pail)
- NSN: 6840-01-656-7851 (Case of 4 each Gallon (3.8 Liter) Bottles)
- T.O.: 1-1-691, 1C-130A-23 and 1C-5A-23-1



For more information contact us :
zipchem@addevmaterials.com



Part of



ADDEV
MATERIALS



AIRCRAFT CLEANERS & DISINFECTANTS

CALLA® 1452



Page 3 of 11

Product description:

NEUTRAL DISINFECTANT CLEANER

APPLICATIONS:

Disinfection – To disinfect inanimate, hard non-porous surfaces, add 4 ounces of **Calla® 1452** Neutral Disinfectant Cleaner per gallon of water. Apply solution with a mop, cloth, sponge, hand pump trigger sprayer, or low pressure coarse sprayer so as to wet all surfaces thoroughly. Allow to remain wet for 10 minutes, then remove excess liquid. For sprayer applications, spray 6-8 inches from surface, rub with brush, sponge, or cloth. Do not breathe spray mist. For heavily soiled areas, a pre-cleaning step is required.

Fungicidal Activity – At the 4 ounce per gallon dilution, **Calla® 1452** is fungicidal against the pathogenic fungi, *Trichophyton Mentagrophytes* (*Athlete's Foot Fungus*) (*a cause of ringworm*) and *Candida Albicans*. Apply solution with a cloth, sponge, or hand pump trigger sprayer to hard, non-porous surfaces. Allow the surface to remain wet for 10 minutes, then remove excess liquid. Diluted **Calla® 1452** should be applied daily or more frequently with heavy facility use.

Mildewstat – To control mold and mildew (*Aspergillus niger*) and the odors they cause on pre-cleaned, hard, non-porous inanimate surfaces, add 4 ounces of **Calla® 1452** per gallon of water. Apply solution with a cloth, mop, sponge, or hand pump trigger sprayer making sure to wet all surfaces completely. Let air dry. Prepare a fresh solution for each use. Repeat application at weekly intervals or when mildew growth appears.



For more information contact us :
zipchem@addevmaterials.com



Part of



ADDEV
MATERIALS



AIRCRAFT CLEANERS & DISINFECTANTS

CALLA® 1452



Page 4 of 11

Product description: **NEUTRAL DISINFECTANT CLEANER**

VIRUCIDAL DATA:

Results:

Test Organism	Sample	Titer Reduction	Contact Time
*SARS-Related Coronavirus 2 [SARS-CoV-2] [USA-WA1/2020] [BEI NR-52281]	A B	-	1 minute
*Avian Influenza A Virus (H3N2) (Avian Ressortant) (ATCC VR-2072)	A B	≥4.25 log ₁₀ ≥4.25 log ₁₀	10 minutes
*Avian Influenza Virus, Type A (Turkey/WIS/66) (H9N2)	A B	≥4.0 log ₁₀ ≥4.0 log ₁₀	10 minutes
*Bovine Rhinotracheitis, strain LA (ATCC VR-188)	A B	≥5.0 log ₁₀ ≥5.0 log ₁₀	10 minutes
#Bovine Viral Diarrhea Virus (BVDV)	A B	5.9 log ₁₀ 5.9 log ₁₀	10 minutes
*Canine Distemper Virus, strain Lederle (ATCC VR-128)	A B	≥6.25 log ₁₀ ≥6.25 log ₁₀	10 minutes
Feline Leukemia (VR-717)	-	-	10 minutes
*Feline Picornavirus, strain FRV (ATCC VR-649)	A B	≥4.25 log ₁₀ ≥4.25 log ₁₀	10 minutes
†Hepatitis B Virus (HBV) (Duck Hepatitis B Virus-DHBV)	A B	4.5 log ₁₀ 4.7 log ₁₀	10 minutes
#Hepatitis C Virus (HCV) (Bovine Viral Diarrhea Virus-BVDV)	A B	5.9 log ₁₀ 5.9 log ₁₀	10 minutes
*Herpes Simplex Type 1 (ATCC VR-260)	A B	≥5.0 log ₁₀ ≥5.0 log ₁₀	10 minutes
*Herpes Simplex Type 2 (ATCC VR-734)	A B	≥6.0 log ₁₀ ≥6.0 log ₁₀	10 minutes
*Human Immunodeficiency Virus, HTLV-IIIRF, strain of HIV-1 (associated with AIDS)	A B	≥3.5 log ₁₀ ≥3.5 log ₁₀	10 minutes
*Human Immunodeficiency Virus type 2 (HIV-2), strain CBL-20	A B	≥3.25 log ₁₀ ≥3.25 log ₁₀	10 minutes
*Human Coronavirus (ATCC VR-740, strain 229E)	A B	≥3.0 log ₁₀ ≥3.0 log ₁₀	10 minutes



AIRCRAFT CLEANERS & DISINFECTANTS

CALLA® 1452



Page 5 of 11

Product description: **NEUTRAL DISINFECTANT CLEANER**

VIRUCIDAL DATA (CONTINUED FROM PAGE 4):

Test Organism	Sample	Titer Reduction	Contact Time
*Influenza A2, strain Hong Kong (ATCC VR-544)	A B	$\geq 4.25 \log_{10}$ $\geq 4.25 \log_{10}$	10 minutes
*Paramyxovirus (Mumps) (ATCC VR-1438)	A B	$\geq 3.0 \log_{10}$ $\geq 3.0 \log_{10}$	10 minutes
*Porcine Respiratory & Reproductive Syndrome Virus (PRRSV), strain NVSL	A B	$\geq 5.0 \log_{10}$ $\geq 5.0 \log_{10}$	10 minutes
*Pseudorabies, strain Aujeszky (ATCC VR-135)	A B	$\geq 5.25 \log_{10}$ $\geq 5.25 \log_{10}$	10 minutes
*Rabies Virus (attenuated CDC ERA strain)	A B	$3.0 \log_{10}$ $3.0 \log_{10}$	10 minutes
*Rotavirus, strain SA-11 (ATCC VR-899)	A B	$4.5 \log_{10}$ $4.5 \log_{10}$	10 minutes
*SARS Associated Coronavirus (ZeptoMetrix)	A B	$3.03 \log_{10}$ $3.03 \log_{10}$	10 minutes
*Vaccinia, strain WR (ATCC VR-119)	A B	$\geq 5.5 \log_{10}$ $\geq 5.5 \log_{10}$	10 minutes

Test Method: U.S. E.P.A. Pesticide Assessment Guidelines, Subdivision G: Product Performance, Section 91-2 (f), and Section 91-30, (d), (e), November 1982.

Protocols for Testing the Efficacy of Disinfectants against Hepatitis B Virus (HBV) (EPA, Federal Register, Vol. 65, No. 166, 8/25/2000, p. 51828).

Protocol for Testing Disinfectants against Hepatitis C Virus using Bovine Viral Diarrhea Virus as approved by the U.S. EPA on August 15, 2002.

Test Conditions: 10 minute contact time, 5% organic soil load, sterile glass petri dishes, 400 ppm hard water, 21-24°C (70°F-75°F) exposure temperature, and 4 oz per gallon dilution.

Conclusions: Under the conditions of this investigation, **Calla® 1452** demonstrated virucidal activity against *SARS-Related Coronavirus 2 (SARS-CoV-2)*, *Avian Influenza A Virus (H3N2)*, *Avian Influenza Virus, Type A (H9N2)*, *Bovine Rhinotracheitis*, *Bovine Viral Diarrhea Virus (BVDV)*, *Canine Distemper Virus*, *Feline Leukemia (VR-717)*, *Feline Picornavirus*, *Hepatitis B Virus (HBV)*, *Hepatitis C Virus (HCV)*, *Herpes Simplex Type 1*, *Herpes Simplex Type 2*, *Human Coronavirus*, *Human Immunodeficiency Virus (HIV-1)*, *Human Immunodeficiency Virus Type 2 (HIV-2)*, *Influenza A2*, *Paramyxovirus (Mumps)*, *Porcine Respiratory & Reproductive Syndrome Virus (PRRSV)*, *Pseudorabies*, *Rabies Virus*, *Rotavirus*, *SARS Associated Coronavirus*, and *Vaccinia*, according to criteria established by the U.S. Environmental Protection Agency for registration and labeling of a disinfectant product as a virucide.



AIRCRAFT CLEANERS & DISINFECTANTS

CALLA® 1452



Page 6 of 11

Product description:
NEUTRAL DISINFECTANT CLEANER

DISINFECTION DATA:

Results:

Test Organism	No. of Carriers			
	Sample	Exposed	Positive	Contact Time
Ampicillin resistant Acinetobacter baumannii (clinical isolate-Fairfax Hospital CI 02001)	A	10	0	10 minutes
	B	10	0	
Bactrim resistant Acinetobacter baumannii (clinical isolate-Fairfax Hospital CI 02001)	A	10	0	10 minutes
	B	10	0	
Bordetella bronchiseptica (ATCC 31437)	A	10	0	10 minutes
	B	10	0	
Cefazolin resistant Acinetobacter baumannii (clinical isolate-Fairfax Hospital CI 02001)	A	10	0	10 minutes
	B	10	0	
Ceftazidime resistant Acinetobacter baumannii (clinical isolate-Fairfax Hospital CI 02001)	A	10	0	10 minutes
	B	10	0	
Ceftriaxone resistant Acinetobacter baumannii (clinical isolate-Fairfax Hospital CI 02001)	A	10	0	10 minutes
	B	10	0	
Ciprofloxacin resistant Acinetobacter baumannii (clinical isolate-Fairfax Hospital CI 02001)	A	10	0	10 minutes
	B	10	0	
Community Associated Methicillin Resistant Staphylococcus aureus (CA-MRSA) (NRS 123, Genotype USA400)	A	10	0	10 minutes
	B	10	0	
	C	10	0	
Community Associated Methicillin Resistant Staphylococcus aureus (CA-MRSA) (NRS 384, Genotype USA300)	A	10	0	10 minutes
	B	10	0	
	C	10	0	
Corynebacterium ammoniagenes (ATCC 6871)	A	10	0	10 minutes
	B	10	0	
Enterobacter aerogenes (ATCC 13048)	A	10	0	10 minutes
	B	10	0	
Enterobacter cloacae (ATCC 23355)	A	10	0	10 minutes
	B	10	0	
Enterobacter cloacae (clinical isolate)	A	10	0	10 minutes
	B	10	0	
Enterococcus faecalis (ATCC 19433)	A	10	0	10 minutes
	B	10	0	

For more information contact us :
zipchem@addevmaterials.com



Part of



ADDEV
MATERIALS



AIRCRAFT CLEANERS & DISINFECTANTS

CALLA® 1452



Page 7 of 11

Product description:
NEUTRAL DISINFECTANT CLEANER

DISINFECTION DATA (CONTINUED FROM PAGE 6):

Test Organism	No. of Carriers			
	Sample	Exposed	Positive	Contact Time
Enterococcus faecalis (clinical isolate)	A	10	0	10 minutes
	B	10	0	
Escherichia coli (ATCC 11229)	A	10	0	10 minutes
	B	10	0	
Escherichia coli (clinical isolate)	A	10	0	10 minutes
	B	10	0	
Escherichia coli O111:H8 (BAA-184)	-	-	-	10 minutes
Fusobacterium necrophorum (ATCC 27852)	A	10	0	10 minutes
	B	10	0	
Gentamicin resistant Acinetobacter baumannii (clinical isolate-Fairfax Hospital CI 02001)	A	10	0	10 minutes
	B	10	0	
Klebsiella pneumoniae subsp. pneumoniae (ATCC 13883)	A	10	0	10 minutes
	B	10	0	
Lactobacillus casei subsp. rhamnosus (ATCC 7469)	A	10	0	10 minutes
	B	10	0	
Levofloxacin resistant Acinetobacter baumannii (clinical isolate-Fairfax Hospital CI 02001)	A	10	0	10 minutes
	B	10	0	
Listeria monocytogenes (ATCC 35152)	A	10	0	10 minutes
	B	10	0	
Methicillin Resistant Staphylococcus aureus (MRSA) (ATCC 33592)	A	10	0	10 minutes
	B	10	0	
Pasteurella multocida (ATCC 7707)	A	10	0	10 minutes
	B	10	0	
Proteus mirabilis (ATCC 9921)	A	10	0	10 minutes
	B	10	0	
Proteus mirabilis (ATCC 25933)	A	10	0	10 minutes
	B	10	0	
Proteus vulgaris (ATCC 13315)	A	10	0	10 minutes
	B	10	0	
Pseudomonas aeruginosa PRD-10 (ATCC 15442)	A	60	0	10 minutes
	B	60	0	
	C	60	1	



AIRCRAFT CLEANERS & DISINFECTANTS

CALLA® 1452



Page 8 of 11

Product description:

NEUTRAL DISINFECTANT CLEANER

DISINFECTION DATA (CONTINUED FROM PAGE 7):

Test Organism	No. of Carriers			
	Sample	Exposed	Positive	Contact Time
Salmonella enterica subsp. enterica serotype choleraesuis (ATCC 10708)	A	60	0	10 minutes
	B	60	0	
	C	60	1	
Salmonella enterica subsp. enterica serotype paratyphi B (ATCC 8759)	A	10	0	10 minutes
	B	10	0	
Salmonella enterica subsp. enterica serotype pullorum (ATCC 9120)	A	10	0	10 minutes
	B	10	0	
Salmonella enterica subsp. enterica serotype typhi (ATCC 6539)	A	10	0	10 minutes
	B	10	0	
Salmonella enterica subsp. enterica serotype typhimurium (ATCC 14028)	A	10	0	10 minutes
	B	10	0	
Salmonella enteritidis subsp. Enterica serotype enteritidis (ATCC 13076)	A	10	0	10 minutes
	B	10	0	
Serratia marcescens (ATCC 8100)	A	10	0	10 minutes
	B	10	0	
Shigella dysenteriae (ATCC 12180)	A	10	0	10 minutes
	B	10	0	
Shigella flexneri Type 2b (ATCC 12022)	A	10	0	10 minutes
	B	10	0	
Shigella sonnei (ATCC 25931)	A	10	0	10 minutes
	B	10	0	
Staphylococcus aureus (ATCC 6538)	A	60	1	10 minutes
	B	60	1	
	C	60	1	
Staphylococcus aureus subsp. aureus (ATCC 33592)	A	10	0	10 minutes
	B	10	0	
Staphylococcus aureus (clinical isolate)	A	10	0	10 minutes
	B	10	0	
Staphylococcus epidermidis (ATCC 29641)	A	10	0	10 minutes
	B	10	0	
Staphylococcus epidermidis (clinical isolate)	A	10	0	10 minutes
	B	10	0	
Streptococcus pyogenes Group A (ATCC 19615)	A	10	0	10 minutes
	B	10	0	



For more information contact us :
zipchem@addevmaterials.com



Part of



ADDEV
MATERIALS



AIRCRAFT CLEANERS & DISINFECTANTS

CALLA® 1452



Page 9 of 11

Product description: **NEUTRAL DISINFECTANT CLEANER**

DISINFECTION DATA (CONTINUED FROM PAGE 8):

Test Organism	No. of Carriers			
	Sample	Exposed	Positive	Contact Time
Streptococcus pyogenes (clinical-flesh eating strain, BIRD M3)	A	10	0	10 minutes
	B	10	0	
Tobramycin resistant Acinetobacter baumannii (clinical isolate-Fairfax Hospital CI 02001)	A	10	0	10 minutes
	B	10	0	
Vancomycin Resistant Enterococcus faecalis (VRE) (ATCC 51575)	A	10	0	10 minutes
	B	10	0	
Vancomycin Intermediate Resistant Staphylococcus aureus (VISA) (HIP-5836)	A	10	0	10 minutes
	B	10	0	
Xanthomonas maltophilia (clinical isolate)	A	10	0	10 minutes
	B	10	0	
Xanthomonas axonopodis pathovar citri @ a dilution ratio of 1:13.5 (2000 ppm active quaternary)	A	10	0	-
	B	10	0	

Test Method: AOAC Use Dilution

Test Conditions: 5% organic soil load, 10 minute contact time, stainless steel carrier substrates, 400 ppm hard water, 20°C (68°F) exposure temperature, and 4 oz per gallon dilution.

Conclusions: Under the conditions of this investigation, **Calla® 1452** demonstrated disinfectant activity against *Staphylococcus aureus*, *Salmonella (choleraesuis) enterica*, *Pseudomonas aeruginosa PRD-10*, *Ampicillin resistant Acinetobacter baumannii*, *Bactrim resistant Acinetobacter baumannii*, *Bordetella bronchiseptica*, *Cefazolin resistant Acinetobacter baumannii*, *Ceftazidime resistant Acinetobacter baumannii*, *Ceftriaxone resistant Acinetobacter baumannii*, *Ciprofloxacin resistant Acinetobacter baumannii*, *Community Associated Methicillin Resistant Staphylococcus aureus (CAMRSA) (NRS 123, Genotype USA400)*, *Community Associated Methicillin Resistant Staphylococcus aureus (CA-MRSA) (NRS384, Genotype USA300)*, *Corynebacterium ammoniagenes*, *Enterobacter aerogenes*, *Enterobacter cloacae*, *Enterococcus faecalis*, *Escherichia coli*, *Fusobacterium necrophorum*, *Gentamicin resistant Acinetobacter baumannii*, *Levofloxacin resistant Acinetobacter baumannii*, *Klebsiella pneumonia subsp. pneumoniae*, *Lactobacillus casei subsp. rhamnosus*, *Listeria monocytogenes*, *Methicillin Resistant Staphylococcus aureus (MRSA)*, *Pasteurella multocida*, *Proteus mirabilis (ATCC 9921)*, *Proteus mirabilis (ATCC 25933)*, *Proteus vulgaris*, *Salmonella (paratyphi B) enterica*, *Salmonella (pullorum) enterica*, *Salmonella (typhi) enterica*, *Salmonella (typhimurium) enterica*, *Salmonella (enteritidis) enterica*, *Serratia marcescens*, *Shigella dysenteriae*, *Shigella flexneri Type 2b*, *Shigella sonnei*, *Staphylococcus aureus subsp. aureus*, *Staphylococcus epidermidis*, *Streptococcus pyogenes Group A*, *Streptococcus pyogenes (clinical flesh eating strain, BIRD M3)*, *Tobramycin resistant Acinetobacter baumannii*, *Vancomycin Resistant Enterococcus faecalis (VRE)*, *Vancomycin Intermediate Resistant Staphylococcus aureus (VISA)*, and *Xanthomonas maltophilia* according to criteria established by the U.S. Environmental Protection Agency for registration and labeling of a disinfectant product as a bactericide. At a dilution ratio of **1:13.5 (2000 ppm active quaternary)**, **Calla® 1452** demonstrated disinfectant activity against *Xanthomonas axonopodis pathovar citri (Citrus Canker Disease)*.

For more information contact us :
 zipchem@addevmaterials.com





AIRCRAFT CLEANERS & DISINFECTANTS

CALLA® 1452



Page 10 of 11

Product description: **NEUTRAL DISINFECTANT CLEANER**

FUNGICIDAL DATA:

Results:

Test Organism	Sample	Exposure Time (min.) vs. Growth				Contact Time
		5 Min	10 Min	15 Min		
Trichophyton interdigitale (formerly mentagrophytes Trichophyton) (ATCC 9533) (Athletes Foot Fungus) (a cause of ringworm) (a cause of ringworm of the foot)	A	+	0	0	10 minutes	
	B	+	0	0		
Candida albicans (ATCC 10231)	A	0	0	0	10 minutes	
	B	0	0	0		

Test Method: AOAC Fungicidal Activity of Disinfectants

Test Conditions: 5% organic soil load, 20°C (68°F) exposure temperature, 200 ppm hard water, and 4 oz per gallon dilution.

Conclusions: Under the conditions of this investigation, **Calla® 1452** demonstrated fungicidal activity against *Trichophyton mentagrophytes* and *Candida albicans*, according to criteria established by the U.S. Environmental Protection Agency for registration and labeling of a disinfectant product as a fungicide.

MILDEW FUNGISTATIC DATA:

Results:

Sample	No. of Exposed Tiles	No. of Tiles Showing Growth
A	10	0
B	10	0
Control	10	10

Test Method: Hard Surface Mildew Fungistatic Test

Test Organism: *Aspergillus niger* (ATCC 6275)

Test Conditions: 400 ppm hard water, ceramic tile carriers, and 4 oz per gallon dilution.

Contact Time For *Aspergillus niger* (ATCC 6275): 10 minutes

Conclusion: Under the conditions of this investigation, **Calla® 1452** demonstrated fungistatic activity against *Aspergillus niger*, according to criteria established by the U.S. Environmental Protection Agency for registration and labeling of a disinfectant product as a fungistat.



AIRCRAFT CLEANERS & DISINFECTANTS

CALLA® 1452



Page 11 of 11

Product description:

NEUTRAL DISINFECTANT CLEANER

PHYSICAL PROPERTIES:

- ▶ **Density:** 8.38 lbs/gal (1004 grams/Liter)
- ▶ **Flash Point:** Not Flammable
- ▶ **pH:** 6.4

AVAILABLE PACK SIZES:

- ▶ Case of 4 each Gallon (4 each of 3.8 Liter) Bottles-009450
- ▶ 5 Gallon (18.9 Liter) Pails-007247



For more information contact us :
zipchem@addevmaterials.com



Part of



ADDEV
MATERIALS